



HERKULES PLUS

Installation instruction
Инструкция монтажа

$H = 60 \text{ mm}$

G [mm]	16	18	22	25	28	32	40
x	2	2	3	3	4	4	6

2 A

$D[\text{mm}] = \frac{L[\text{mm}] - x - 5}{2}$

2 B

$D[\text{mm}] = \frac{L[\text{mm}] - 2x - 8}{4}$

D ≤	600 mm	750 mm
HERKULES PLUS	2 x 25 kg 4 x 25 kg	2 x 40 kg 4 x 40 kg

Ø3,5x16

45mm, 40mm, Ø10, 45mm, 35mm, Ø10, 45mm, 40mm

Ø4x40

Ø4x40

Ø3,5x16


Ø4x20

40mm + x

6

5

40mm + x



1:1